

DATA BOMBER


ARMED POLICE

© EIGHTING / RAIZING 1998

OPERATOR'S MANUAL

SETTINGS

- EDGE CONNECTOR
- JAMMA STANDARD
- VERTICAL SCREEN
- CONTROL PANEL



8WAY JOYSTICK



SHOT



BOMBER

※Maximum credits-9.

JAMMA

SOLDER SIDE				PARTS SIDE
GND	A	1		GND
GND	B	2		GND
+5V	C	3		+5V
+5V	D	4		+5V
N.C.	E	5		N.C.
+12V	F	6		+12V
	H	7		
COIN COUNTER 2 (COIN LOCK OUT 2)	J	8		COIN COUNTER 1 (COIN LOCK OUT 1)
SP(-)	K	9		SP(+)
N.C.	M	11		N.C.
VIDEO GREEN	N	12		VIDEO RED
VIDEO SYNC	P	13		VIDEO BLUE
SERVICE SW	R	14		VIDEO GND
N.C.	S	15		
COIN SW 2	T	16		COIN SW 1
START SW 2	U	17		START SW 1
2P UP	V	18		1P UP
2P DOWN	W	19		1P DOWN
2P LEFT	X	20		1P LEFT
2P RIGHT	Y	21		1P RIGHT
2P PUSH 1	Z	22		1P PUSH 1
2P PUSH 2	a	23		1P PUSH 2
2P PUSH 3	b	24		1P PUSH 3
N.C.	c	25		N.C.
N.C.	d	26		N.C.
GND	e	27		GND
GND	f	28		GND

